

PFL Supercem - Test Pot

PeterFell
SPECIALISTS IN COLOURED CONCRETE

PFL Supercem is a traditional cement paint for use on cementitious walls, including plaster, masonry, and concrete blocks.

Description:

Welcome to the world of Supercem cement paint. This test pot will enable you to explore the simplistic elegance and natural look generated by this durable, practical product.

The test pot consists of two components:

- (i) 200 g of Supercem (white powder)
- (ii) A colour pottle containing the correct proportion of colour and water
- DO NOT add any more liquid to test pot.

Test pot should be applied as described below. For full technical information and product application please refer to the Supercem technical booklet.

Precautions:

Ensure Supercem is completely dry before assessing colour. To get a true indication of Supercem colour and appearance, the test area should be viewed at different times to truly get the advantage of the interplay of light on the textured surface.

Application:

Equipment: Brush, garden sprayer/mister.

Preparation: All areas to be coated with Supercem must be sound, clean and free from oils, grease or surface contaminants. Any existing coatings should be completely removed. Loose material, dirt and dust must be removed by brushing and if necessary washing and waterblasting.

Application:

- Shake the colour pottle well to ensure colour is completely mixed through
- Add entire contents of colour pottle to Supercem powder slowly while constantly stirring.
- Mix until Supercem is of even colour and uniform consistency.
- Wet mist area Supercem is to be applied – DO NOT HOSE OR SATURATE!
- Give Supercem another mix.
- Apply half of the Supercem test pot to the prepared area – the test pot will provide two-coat coverage of approximately 0.5 m².
- Apply liberally in 'white wash' style with bold brush strokes. Some of the natural appeal of Supercem is generated from the texture generated during application.
- Leave area to dry (touch dry). The time taken for is dependent of temperature, season etc and will vary between 5 –15 minutes.
- When satisfied Supercem is dry, give the remaining Supercem another good stir and apply over the first coat. This will simulate a two coat application.
- If when the second coat is dry and is powdery when touched, finely wet mist to complete curing.

Cleanup: All tools can be cleaned in water.

Safety and Handling:

PFL Supercem is considered non-hazardous. For full safety information refer to MSDS or contact Peter Fell Ltd.